



## Instruction:

Place newspaper or rag on work area.

Remove excess mud, dirt and sand from chain by Super B TB-1711 folding brush.

Super B TB-1711 is specifically designed to clean dirt and grime on cassette, freewheel, chain and other parts. (see picture A&B)

1. Make sure that bike is steady on a Super B workstand and then adjust the rear derailleur to make the chain stay on the smallest chainring.
2. Position the chain cleaner on the lower portion of the chain, mid-way between freewheel and crank set. (see picture C)
3. Cover the lid and then slide handle firmly into body of the chain cleaner. (see picture C)
4. Fill with degreaser TB-3225 to "Fill" line. Do not overfill. (see picture D)
5. Crank crankset slowly backwards (counter-clockwise) for several rounds to clean the chain. (see picture E)
6. Re-lubricate the chain by TB-3210 or TB-3215(optional). (see picture F)
7. Clean up spills immediately, empty the chain cleaner and rinse with water and then squeeze fluid out from sponge.  
Always dispose of cleaning fluid and rag properly.
8. To maximize the efficiency of the chain cleaner and avoid damaging it, please do not use the chain cleaner on the chain with caked dirt on it.



## 使用說明：

請在工作區域鋪上報紙或布

請先利用TB-1711折疊清潔刷來清潔泥垢、灰塵或泥沙

TB-1711有著易於清潔齒片和鏈條上的泥垢和灰塵的特殊設計 (如圖 A、B所示)

1. 先將自行車固定於Super B修理架，並調整變速器將鏈條置於最小的齒片。
2. 將洗鏈器置於大盤和飛輪中間的下方鏈條。(如圖 C所示)
3. 蓋上洗鏈器上蓋，輕輕的將手柄卡入洗鏈器背面，並確認手柄已完整地固定洗鏈器。(如圖C所示)
4. 注入環保除油劑TB-3225到標記"FILL"線的位置，請注意不要注入超過標記位置。(如圖D所示)
5. 慢慢地以逆時鐘方向旋轉曲柄數圈來清潔鏈條。(如圖E所示)
6. 清潔後請使用鏈條油TB-3210或是TB-3215 (選購) 來潤滑鏈條。(如圖F所示)
7. 請將多餘的鏈條油擦拭乾淨，使用清水清洗洗鏈器，並擠乾海綿內的水分，請妥善處理使用過的清潔劑與抹布。
8. 請勿使用於泥垢已結塊的鏈條，因為有可能降低洗鏈器的效能並增加損耗。

