


## 1 Parts description



(Picture 1)

NO.	PART	Q'TY
①	Tripod uprights	2
②	Connector	1
③	Support tubes	2
④	T-shaped tubes	2

## 2 Assembly


1. Post the tripod uprights ① steady. (see picture 1)
2. Move T-shaped tubes ④ to needed height.
3. Lock quick release to tighten T-shaped tubes ④ after connected with support tubes ③. (see picture 1&3)
4. Must make support tubes ③ contact with rivet. (see picture 2)
5. Lock quick release to tighten connectors ②.

## 3 Instruction


1. Make sure all the quick releases are locked.
2. Adjust the height to make the support tubes ③ in horizontal condition.
3. Hold up to the bikes by the nose of the saddle.



Max weight is 120kg (264lbs)




(Picture 2)



(Picture 3)

## 1 零件名稱及數量



(圖一)

編號	名稱	數量
①	三腳架	2
②	連結套管	1
③	支撐桿	2
④	T型管	2

## 2 組裝步驟


1. 平穩設定好三腳架①。(如圖一所示)
2. 移動T型管④至所需高度。
3. 將支撐桿③穿入T型管④，並將T型管④上快拆鎖緊。(如圖一、圖三所示)
4. 將支撐桿③穿入連結套管②，並確認支撐桿③接觸鉚釘。(如圖二所示)
5. 將連結套管②上快拆鎖緊。

## 3 使用說明


1. 使用前請確認所有快拆都鎖緊。
2. 調整兩邊T型管④高度讓支撐桿③保持水平。
3. 利用自行車坐墊前端將自行車吊掛至支撐桿③上。



最大承受重量為120公斤 (264磅)



(圖二)



(圖三)